

General guidelines only for installation of Models: **NGP, NGS, NWR and NPL** non-rated access doors.

Local codes and / or Authority having jurisdiction should be followed.

Wall or ceiling opening is framed into the size of door being ordered.

We undersize our door frames by 6mm (1/4”).

(18” x 18” door ordering size, framed opening should be 18” x 18”. Do not undersize your framing.)

1. Insert the door frame into the opening to check fit. Flanges should seat firmly against the surface.
2. Remove door and apply a generous amount of a permanently flexible sealant to door flange and frame as needed to seal the unit into the framed opening.
3. Secure along the hinge side first taking care to square the door panel up. The door panel should be installed square with the door frame.
4. Once squared up fasten through holes provided in frame.

Do not over torque fasteners to avoid twisting / distorting the frame.

5. Gaskets should be cleaned of any sealant with a damp lint-free cloth. Do not apply mineral oils or other lubricants to the gasket as they can cause the gasket to break down over time.
6. Operate door a few times to check that no fasteners or other items interfere with its function.

Maintenance:

Operate access door as needed to check performance.

Lubricate moving parts such as hinges and latches with a non-staining silicone spray lube as required.

Clean as required with a mild soap / dishwashing detergent; water solution.

Gaskets can be cleaned with a damp, lint-free cloth. Do not apply mineral oils or other lubricants to the gasket as they can cause the gasket to break down over time.

These doors are not designed to support a live load.

Van-Met Access Doors by:
MAXAM METAL PRODUCTS LTD.
Telephone: +1(604) 433-4243
Fax: +1(604) 433-4148
Toll Free Telephone: 1-866-446-2926
Toll Free Fax: 1-866-436-2926

www.maxammetal.com